


## Robic SC-512 Countdown Timer Operating Instructions

THANK YOU for buying the SC-512 Countdown Timer. Your purchase brings you an easy-to-use, World-Class Timer perfect for keeping track of time remaining in any game, event or activity.

Your Game & Activity Countdown Timer was developed to count down from any preset time to completion, silently or with an Audible Beep Confirmation, and includes a Pause function for time-outs and a Lock Function to protect current readings. In order to ensure that you receive the maximum enjoyment from your Countdown Timer, BEFORE USING, PLEASE TAKE A MOMENT TO REVIEW THIS OPERATION GUIDE TO FULLY UNDERSTAND HOW YOUR TIMER WORKS.

Counts down from any time you enter.  
Shows time remaining.



Pusher A: "SET"

Pusher B: "RESET"

Pusher C: Start/Stop-Advance (Grey Middle Pusher)

Pusher D: "LOCK"

Press and Hold both A and B to select beep tone--((●))—or silent operation. **Pre Alert and Completion time beep tones always sound whether Silent or Beep Tone activated.**

**Countdown ▼:** You may countdown in seconds from 99 minutes 59 seconds or in minutes from 9999 minutes. With the time value set to zero, press A to select minutes or seconds (colon ":" appears).

Enter the time by pressing and holding A > 3 seconds. The digit on the far right appears flashing. Advance the value by pressing C. Then, press A to set and press C to advance each successive digit. Press D to load your time and exit the setting process.

After entering the preset time, press C to start counting down. You may press C to stop (STOP appears) and restart the timing as required. If the Beep tone is active, single Pre alert beeps sound with 30, 3, 2 and 1 seconds remaining. Upon completion, the SC-512 will sound a rapid beep tone and reset to the preset time. **Pre Alert and Completion time beep tones always sound whether Silent or Beep Tone operation is chosen.**

You may set a new Preset time upon completion by Pressing and Holding A for > 3 seconds and proceeding as described above after **Countdown**.

LOCK feature: The SC-512 will Lock a time into place at anytime the timer is not active (running) by pressing D > 3 seconds. The “lock” icon appears in the display. Locking the timer prevents all operation and accidentally resetting the time

#### **LIMITED WARRANTY OUR BASIC POLICY**

Marshall –Browning International Corporation (MBI Corp.) warrants to the original owner, this timepiece (excluding battery, lanyard, clip, band or strap) for the period of one year from the original purchase date. This limited warranty is given by MBI Corp. and not by the dealer from whom the timepiece was purchased.

---

#### **THE WARRANTY PROCESS – WHAT IS COVERED BY THE WARRANTY**

If the timepiece develops a manufacturing defect within the one year limited warranty period, it will be either repaired or replaced (at MBI Corp.’s option) with a timepiece of equal value, providing the original owner submits the following:

1. Proof of purchase, i.e. a validated store receipt showing date of purchase.
2. A check or money order (no cash, please) in the amount of \$7.50 to cover the cost of shipping and handling

#### **WHAT IS NOT COVERED BY THE WARRANTY**

- A. MBI Corp. will not repair defects of damages caused by or showing evidence of:
  1. Improper or unauthorized service.
  2. Misuse, tampering, abuse or mistreatment of the timepiece.
  3. Damage to the case or viable cracking of the lens.
  4. Moisture damage, if the product is a non-water-resistant timepiece.
- B. If we find that the battery is the cause of the defect, MBI Corp. reserves the right to charge your (\$7.50) for a new replacement.

MBI Corp. is not liable for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

#### **YOUR RIGHTS UNDER IMPLIED WARRANTIES AND STATE LAW.**

MBI Corp. limits the duration of any warrant implied by state law, including the implied warrant of merchantability, to one year from the date of original purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation

may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**CARING FOR YOUR TIMEPIECE SC-512**

Proper care of your timepiece will provide many years of enjoyment. We recommend that:

1. The battery be replaced at once when it becomes depleted. Please ask your local retailer to replace the battery for you using **LR44 or equivalent**.
2. The lens be replaced immediately if it becomes damaged, as contamination from dust, moisture, and other foreign substances will damage the module.
3. If the timepiece is not marked "water-resistant," avoid immersing or exposing it to water, steam, or other forms of moisture.

**WHEN YOU REQUIRE SERVICE**

If your timepiece ever requires factory servicing, you can send it directly to:

MBI Corp. c/o Frazier Sports 6600 Broad Avenue Waco TX 76712

We strongly recommend that when sending it through the mail, you send the product insured, return receipt requested, so that if a problem in shipping arises, you can trace it through the originating post office. You will be billed for all services deemed out of warranty; and since we reserve the right to substitute with a replacement product of equal or greater value, NEVER include a personal item, such as a watchband, with the repair request.

---

Robic...Timers & pedometers for champions at every level! Please call (203) 264-2702 for a free catalog.

[www.RobicTimers.com](http://www.RobicTimers.com)

10-30-10