


Thank you for buying the Robic SC-589. Your purchase brings you a world class watch with a vast array of advanced timekeeping functions.

Please take a few moments to review this operating guide, so that you may become familiar with the SC-589's many capabilities and how you can best access them for your maximum benefit.

FEATURES:

1. Time of Day shown in Hour, Minute, Second, Year, Month, Date.
2. 12 (AM/PM) or 24 Hour Time Display Format with auto calendar.
3. Daily Alarm
4. 1/100 second stopwatch, times to 9 hours 59 minutes and 59.99 seconds.
5. 10 lap and split memory recall of Chronograph readings.
6. Soccer Referee timer and Stoppage Timer keeps track of stoppage time.



Time of day Mode

A) Normal Display:



- ⊙ Press A: Changes display of Year.
- ⊙ Press B: Changes display of 12/24 Hour format.
- ⊙ Press C: Press and hold for 2 seconds to enter into Time Setting Mode.
- ⊙ Press D: To enter into Alarm Mode.

B) Time Setting: Second digits flashing



- ⊙ Press A: To reset Seconds to 00.
- ⊙ Press B: To select sequentially Second, Minute, Hour, Year, Month, Date.
- ⊙ Press C: To complete Time Setting.
- ⊙ Press D: No Function.

Alarm Mode

A) Normal Display:



- ⊙ Press A: Turns Alarm On or Off- Symbol will appear/disappear.
- ⊙ Press B: No Function.
- ⊙ Press C: Press and hold for 2 seconds to enter into Alarm Setting Mode.
- ⊙ Press D: To enter into Chronograph Mode.

B) Alarm Setting: Hour digits flashing



- ⊙ Press A: To set Alarm Hour.
- ⊙ Press B: To select sequentially Alarm Hour, Minute.
- ⊙ Press C: To complete Alarm Setting.
- ⊙ Press D: No Function.

Chronograph Mode

The Chronograph will operate up to 10 hours or 10 Lap/SPLIT times are taken. It will operate as a stopwatch after 10 LAP/SPLIT readings, but will not take any further intermediate readings.



- ⊙ Press A: Starts and Stops the chronograph.
- ⊙ Press B: Take Lap and Split Times when active (running), or, resets to all zeroes when stopped.
- ⊙ Press C: When stopped and reset to all zeros, changes top row between LAP and SPLIT timing. LAP is the interval of time from the previous reading while SPLIT is the accumulation from the start of timing.

To review memory Recall while running or stopped but not reset to all zeros, press C to find readings successively displayed as FAST→SLOW→AVG→then the time readings in ascending order; from the first reading to the last available reading.

- ⊙ Press D: To enter Referee Timer Mode.

Referees Timer Mode: Your Referee Timer is preset to 45 minutes. Time may be set in as full minutes. Seconds cannot be entered into the Countdown Timer.

To review play time in seconds, use the Stoppage Timer as described below.

A) Normal Display:



- ⊙ Press A: Will Start and Stop the Stoppage Timer. Press and hold A for 2 seconds, reset to 00.
The digits will flash when time is active (running) and stop flashing when time is stopped.
Time will display up to 59 minutes 59 seconds, return to Zero and start again.
- ⊙ Press B: To Start and Stop countdown process. Press and hold for 2 seconds to reset to countdown time 45 minutes.

Warning Beep Tone: 30 seconds before the time of Stoppage Timer, the timer will sound a beep tone.

When the Referees Timer and the Stoppage Timer time matches, the timer will sound a beep tone in a different frequency for 10 seconds.

Upon completion of the Countdown Time, the Referees Timer will start counting up, when it exceeds 99'59.99", it will return to 00 and start counting down again.

- ⊙ Press C: No Function when the Referees Timer is active (running). When it is stopped, press and hold for 2 seconds to enter into Countdown Setting mode
- ⊙ Press D: To enter into Time of Day Mode

Your Referee Timer is preset to 45 minutes but may be set to any Countdown Time in full minutes up to 99 minutes. Setting seconds is not possible in the countdown timer.

B) Count Down Setting:

- ⊙ Press A: To set Minute
- ⊙ Press B: No Function
- ⊙ Press C: To complete Count Down Setting
- ⊙ Press D: No Function

LIMITED WARRANTY OUR BASIC POLICY

Marshall –Browning International Corporation (MBI Corp.) warrants to the original owner, this timepiece (excluding battery, less, band or strap) for the period of one year from the original purchase date. This limited warranty is given by MBI Corp. and not by the dealer from whom the timepiece was purchased.

THE WARRANTY PROCESS – WHAT IS COVERED BY THE WARRANTY

If the timepiece develops a manufacturing defect within the one year limited warranty period, it will be either repaired or replaced (at MBI Corp.'s option) with a timepiece of equal value, providing the original owner submits the following:

1. Proof of purchase, i.e. a validated store receipt showing date of purchase.
2. A check or money order (no cash, please) in the amount of \$7.50 to cover the cost of shipping and handling

WHAT IS NOT COVERED BY THE WARRANTY

A. MBI Corp. will not repair defects of damages caused by or showing evidence of:

1. Improper or unauthorized service.
2. Misuse, tampering, abuse or mistreatment of the timepiece.
3. Damage to the case or viable cracking of the lens.
4. Moisture damage, if the product is a non-water-resistant timepiece.

B. If we find that the battery is the cause of the defect, MBI Corp. reserves the right to charge your (\$7.50) for a new replacement.

MBI Corp. is not liable for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

YOUR RIGHTS UNDER IMPLIED WARRANTIES AND STATE LAW.

MBI Corp. limits the duration of any warrant implied by state law, including the implied warrant of merchantability, to one year from the date of original purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

CARING FOR YOUR TIMEPIECE

Proper care of your timepiece will provide many years of enjoyment. We recommend that:

1. The battery be replaced at once when it becomes depleted. Please ask your local retailer to replace the battery for you using CR2032 (Lithium) or equivalent.
2. The lens be replaced immediately if it becomes damaged, as contamination from dust, moisture, and other foreign substances will damage the module.
3. If the timepiece is not marked "water-resistant," avoid immersing or exposing it to water, steam, or other forms of moisture.

WHEN YOU REQUIRE SERVICE

If your timepiece ever requires factory servicing, you can send it directly to:

MBI Corp. c/o Frazier Sports 6600 Broad Avenue Waco TX 76712

We strongly recommend that when sending it through the mail, you send the product insured, return receipt requested, so that if a problem in shipping arises, you can trace it through the originating post office. You will be billed for all services deemed out of warranty; and since we reserve the right to substitute with a replacement product of equal or greater value, NEVER include a personal item, such as a watchband, with the repair request.

Robic...Timers & pedometers for champions at every level! Please call (203) 264-2702 for a free catalog.