


Robic SC-502T Countdown Timer Operating Instructions

THANK YOU for buying the SC-502T Countdown Timer. Your purchase brings you an easy-to-use, World-Class Timer perfect for keeping track of time remaining in any game, event or activity up to 100 minutes.

Your Countdown Timer was developed to count down from any preset time to completion, silently or with an Audible Beep Confirmation, and includes a Pause function for time-outs and a Lock Function to protect current readings. In order to ensure that you receive the maximum enjoyment from your Countdown Timer, **BEFORE USING, PLEASE TAKE A MOMENT TO REVIEW THIS OPERATION GUIDE TO FULLY UNDERSTAND HOW YOUR TIMER WORKS.**

Counts down from any time you enter.
Shows time remaining. May be Stopped and Re-Started. Operates Silently or with an Audible Beep Confirmation.



Pusher A: Set
MINUTES Pusher B:
Set SECONDS
Pusher C: Start/Stop Timer; Silent or Audible Beep Confirmation
Pusher D: Lock/Unlock Timer;

RESET To Operate:

Press or Hold "A" to set Minutes
Press or Hold "B" to set Seconds
Press "C" to start the time counting down.

You may Stop and Restart the timer as necessary by pressing "C"
When the countdown time expires (display shows 00:00), the alarm will sound.
Pressing any Pusher will silence the Alarm and Reset the timer to the Preset time.